



**104037 TAN PURPLE RED**

Use this diagram as a reference when installing 104037 retrofit simulator into vehicle.

Use a factory service manual for reference on finding wire colors which may vary from these diagrams. Be sure you can identify which sensor feed is positive 12 volts and then secure the red pigtail wire to it. Also be sure you can identify which of the sensor wires is ground; secure the tan wire to that connection.

